

Date: Tuesday, 5/16/2006 10:37:16 AM
User: Kim Johnston

Process Sheet

Customer :	CU-DAR001 Dart Helicopters Services	Drawing Name :	0H-58 SKIDTUBE ASSEMBLY
Job Number :	27136A		
Estimate Number :	10475		
P.O. Number :	N/A	Part Number :	D058672041
This Issue :	5/16/2006	S.O. No. :	N/A
Prsht Rev. :	NC	Drawing Number :	D2922 REV A1
First Issue :	N/A	Project Number :	N/A
Previous Run :	27135A	Drawing Revision :	A1
	Type :	Material :	N/A
	LANDING GEAR	Due Date :	6/10/2006
Written By :	<i>See JA COMMENT REKW</i>		Qty: 1 Um: Each
Checked & Approved By :	<i>06.05.16</i>		
Comment :	Est Rev: C 02.06.28 Re-format; ECN 258 KJ Est Rev: D 06.02.06 Added Dt8025 EC		

Additional Product

Job Number:



Seq. #:	Machine Or Operation:	Description :
---------	-----------------------	---------------

1.0	D2620	Bent 206 Skidtube
-----	-------	-------------------



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2620

Bent Tube 3" OD

B26863 Pm '06-05-28

2.0	LANDING GEAR 1	LANDING GEAR RESOURCE 1
-----	----------------	-------------------------

**Comment:** LANDING GEAR RESOURCE 1

1-Deburr Fwd edge of tube

Pm '06-05-28

2-Cut aft end of D2620 bent tube as per dwg D2922

Pm '06-05-28

3-Drill pilot holes using drill jig DT8480 and DT8025 open to 0.312" dia.

Pm '06-05-28

4-Drill holes for wearplates using DT 8487 Open to 0.297" dia.

Pm '06-05-28

5-Drill holes for aft cap as per Dwg D2922 using drill jig DT 8025. Open using #6 Drill Bit

Pm '06-05-28

7-Remove inner indexing ridge on aft end of skidtube as per Dwg D2922

Pm '06-05-28

8-Deburr and Blow out all chips form inside the tube

Pm '06-05-28

9-Weld D2794 cap as per QSI 004 and Dwg D2922. Use aluminum rod.

A/R Aluminum Rod

m19101 / m18839 BE-06-05-28

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Tuesday, 5/16/2006 10:37:16 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27136A

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

3.0

HAND FINISHING1

HAND FINISHING RESOURCE #1



Comment: HAND FINISHING RESOURCE #1

Chemical Conversion Coat as per QSI 005 4.1

Pm' 06-05-250

4.0

D2923

Web



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty	Part Number	Description	Batch
1	D2923	Web	B27146

Pm' 06-05-290

5.0

LANDING GEAR 1

LANDING GEAR RESOURCE 1



Comment: LANDING GEAR RESOURCE 1

1-Open holes to finished size as per Dwg D2922(without cutting fluid)

Pm' 06-05-290

2-Countersink crossbolt spacer holes as per Dwg D2922(without cutting fluid)

Pm' 06-05-290

3-Deburr and Blow out all chips from inside the tube

Pm' 06-05-290

4-Bond D2923 web in place as per QSI 015. Ensure holes lineup

A/R Sikaflex-291

M10001

Sikaflex expire date: *06-11-01*

Pm' 06-05-290

6.0

QC5

INSPECT WORK TO CURRENT STEP



Comment: INSPECT WORK TO CURRENT STEP

DP 06-5-29

7.0

D2794

Cap



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Qty

Qty	Part Number	Description	Batch
1	D2794	Fwd Cap	B 14400

Batch

B 14400 BE 05-05-25 1

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Tuesday, 5/16/2006 10:37:16 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27136A

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description:

8.0

D2649

Crossbolt Spacer



Comment: Qty.: 22.0000 Each(s)/Unit Total: 22.0000 Each(s)

Pick:

Qty Part Number

Description

Batch

22 D2649

Crossbolt spacer

B25864 BE 06-05-31

9.0

LANDING GEAR 1

LANDING GEAR RESOURCE 1



Comment: LANDING GEAR RESOURCE 1

1-Weld D2649 cross bolt spacers as per QSI 004 and Dwg D2922.(Remember to back drill each hole to 0.250" before welding the other side)

A/R Aluminum Rod

m 18839 BE 06-05-31

3-Grind welds flush as per Dwg D2922

4-Counterbore 5/16" x 0.750" deep as per Dwg D2922

> DP06-6-1

10.0

QC5/9

WELD INSPECTION



Comment: WELD INSPECTION

11.0

POWDER COATING

POWDER COATING



Comment: POWDER COATING

Powder Coat White Gloss (Ref: 4.3.5.1) as per QSI 005 4.3

SC DL 06/07/14

12.0

QC3

INSPECT POWDER COAT/CHEMICAL CONVERSION



Comment: INSPECT POWDER COAT/CHEMICAL CONVERSION

DL 06/07/14

13.0

D26483

Wearpad



Comment: Qty.: 5.0000 Each(s)/Unit Total: 5.0000 Each(s)

Pick:

Qty Part Number

Description

Batch

5 D2648-3

Wearpad

B25904

DL 06/07/14

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Tuesday, 5/16/2006 10:37:17 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27136A

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

14.0

D265615

Wearplate



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description

Batch

1 D2656-15 Wearshoe

B24845

15.0

D265621

Wearplate



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description

Batch

1 D2656-21 Wearshoe

B27075

16.0

D2924

Wearshoe



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description

Batch

1 D2924 Wearshoe

M12425

17.0

MS27039108

Screw



Comment: Qty.: 50.0000 Each(s)/Unit Total : 50.0000 Each(s)

Pick:

Qty Part Number Description

Batch

50 MS27039-1-08 Screw

M19551

18.0

AN960JD10L

Washer



Comment: Qty.: 50.0000 Each(s)/Unit Total : 50.0000 Each(s)

Pick:

Qty Part Number Description

Batch

50 AN960JD10L Washer

M101291

DC 06/07/14 (1)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Tuesday, 5/16/2006 10:37:17 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27136A

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

19.0

ALS41032130

Insert



Comment: Qty.: 5.0000 Each(s)/Unit Total : 5.0000 Each(s)

Pick:

Qty Part Number Description Batch

50 ALS4-1032-130 Insert

or (see QSI 017)

M 19393

20.0

D26511

Plug



Comment: Qty.: 20.0000 Each(s)/Unit Total : 20.0000 Each(s)

Pick:

Qty Part Number Description Batch

20 D2651-1 Plugs

13X B25144
7X B25865

21.0

D26513

O-Ring



Comment: Qty.: 20.0000 Each(s)/Unit Total : 20.0000 Each(s)

Pick:

Qty Part Number Description Batch

20 D2651-3 O-Rings

B25866

22.0

D2646

Aft Cap



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)

Pick:

Qty Part Number Description Batch

1 D2646 Aft Cap

B25381

23.0

MS27039108

Screw



Comment: Qty.: 2.0000 Each(s)/Unit Total : 2.0000 Each(s)

Pick:

Qty Part Number Description Batch

2 MS27039-1-08 Screw

M19551

PL 06/07/14 (D)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes ☒ No ☐ DQA: LS Date: 06/07/24

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____

Date: Tuesday, 5/16/2006 10:37:17 AM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: 0H-58 SKIDTUBE ASSEMBLY

Job Number: 27136A

Part Number: D058672041

Job Number:



Seq. #:

Machine Or Operation:

Description :

24.0

AN960JD10L

Washer



Comment: Qty.: 2.0000 Each(s)/Unit Total : 2.0000 Each(s)

Pick:

Qty Part Number Description Batch

2 AN960JD10L Washer M100291

DL 06/07/14 (1)

25.0

HAND FINISHING1

HAND FINISHING RESOURCE #1



Comment: HAND FINISHING RESOURCE #1

1-Install inserts & wearpads as per dwg D2922. Insert a drop of Sikaflex at insert hole before installing wearplates.

A/R Sikaflex-291

Sikaflex expire date: 11/06

2-Install O-Rings D2651-3 on plugs D2651-1 with Petroleum Jelly and install plugs as per Dwg D2922

3-Install D2646 Aft Cap and seal with Sikaflex adhesive.Clean excess adhesive

A/R Sikaflex-291

Sikaflex expire date: 11/06

3- Wing Walk as per Dwg D2922 and QSI 005 4.4

M101266

Batch:

FC

06 07 17 (1)

26.0

QC3/5

INSPECT WORK/WING WALK



Comment: INSPECT WORK/WING WALK

27.0

PACKAGING 1

PACKAGING RESOURCE #1



Comment: PACKAGING RESOURCE #1

Identify and Stock

Location: —

MP 06/07/15

28.0

DC

DOCUMENT CONTROL



Comment: DOCUMENT CONTROL

Inspection Level 21

06.07.20

Job Completion



06.07.19

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Mfg / Design Mgr	Approval QC Inspector

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Design Mgr	Approval QC Inspector
			Initial Design Mgr	Action Description Design Mgr	Sign & Date			

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

NOTE: Date & initial all entries

QA: N/C Closed: _____ Date: _____



DESIGN RF	DRAWN BY RF	DART AEROSPACE USA, INC. BELLEVUE, WA	
CHECKED [Signature]	APPROVED [Signature]	DRAWING NO. D2922	REV. A SHEET 1 OF 2
DATE 99.10.14		TITLE OH-58 SKIDTUBE ASSEMBLY	SCALE NTS
A	99.10.14	NEW ISSUE	
A1	# CP 01.08.20	Ø0.640 WAS Ø0.625	

RELEASED
00.05.11 #

Qty	Part Number	Description
X	D2922-041	SKIDTUBE ASSEMBLY
*	D2600-1	EXTRUSION
1	D2646	AFT CAP
4	D2648-3	WEARPAD
1	D2648-5	WEARPAD
22	D2649	CROSS BOLT SPACER
20	D2651-1	PLUG
20	D2651-3	O-RING
1	D2656-15	WEARSHOE
1	D2656-21	WEARSHOE
1	D2794	CAP
1	D2923	WEB
1	D2924	WEARSHOE
50	AKS7-1032-130 or AKS4-1032-130 or ALS7-1032-130 or ALS4-1032-130	INSERT
52	AN960JD10L	WASHER
52	MS27039-1-08	SCREW

GENERAL NOTES:

- 1) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- 2) LENGTH OF D2600-1 EXTRUSION REQUIRED BEFORE BENDING = 160 INCHES.*
- 3) INSERT D2923 WEB TO LOCATION SHOWN OFF AFT END OF SKIDTUBE AND BOND WEB INTO OUTER TUBE WITH NON-STRUCTURAL SIKAFLEX-241/291 ADHESIVE PER DART QSI 015 AFTER BENDING.
- 4) USE DART DRILL TEMPLATE DT8406 TO LOCATE AND DRILL Ø0.297 HOLES FOR WEARSHOE INSERTS. INSTALL AKS7-1032-130 PER SECTION D-D (50 PLACES) AFTER FINISH. INSTALL MS27039-1-08 SCREWS AND AN960JD10L WASHERS IN ALL INSERTS. SEAL WITH SIKAFLEX-241/291.
- 5) WELDING TO BE DONE PER DART QSI 004.
- 6) FINISH:
ACID ETCH, ALODINE PER DART QSI 005 4.1 PRIOR TO INSERTING D2923 WEB
POWDER COAT ASSEMBLY GLOSS WHITE (REF 4.3.5.1) PER DART QSI 005 4.3
BLACK ANTI-SKID PAINT AS INDICATED TO 0.50 ABOVE LOCATION RIDGE PER DART QSI 005 4.4
- 7) INSERT D2651-1 PLUG C/W D2651-3 O-RING IN HOLES MARKED 'P' (BOTH SIDES OF TUBE) AFTER FINISH (20 PLACES).

SHOP COPY
RETURN TO
ENGINEERING

UNCONTROLLED COPY
SUBJECT TO AMENDMENT
WITHOUT NOTICE

WORK ORDER
NO. 27136A

